

The Collection of 48 Leslie Kits - Service Manuals, Instructions, Schematics, Parts & Original Price List

Kit No.	Part No.	Pages	Date	Name	Organs	Leslies	Parts
Overview & Price List		10	1974 Oct 4				
000126A	062216	3	1967 Apr 12	126 Console Connector Kit	all organs	120, 120C, 145, 147, 247, 247RV	Console Connector Chassis 26-1; Echo Switch Assembly 26-3; Tremolo Switch Assembly 126-2
001122A	547-059338	1	1998 Apr	1122 Console Connector Kit	standard 11-pin Leslie input signals	122, 122A	Chassis 541-059333; Bottom Plate 541-059334
001147A	547-059378	1	1994	1147 11-to 6-pin Connector Kit	standard 11-pin Leslie input signals	147, 147A	Chassis 541-059333; Bottom Plate 541-059334
001174A	047-057676	14		1174 Console Connector Kit	any one, two, three, or four channel organs	all Leslie 11-pin Tone Cabinets (up to four channels)	Console Connector Assembly 009-057678; Console Cable Assembly 011-057692; Control Center Assembly 008-57672; Hardware Package 089-57686; Installation Instructions 047-057676
006122A		1		6122 Console Connector	B-3, C-3, RT-3, self-contained organs	122, 122A	
007022A	113120	6	1974 Oct	7022 Console Connector Kit	pianos providing an output signal of less than 1.5 volts	Leslie Speaker Set Model 60	Control Assembly 112670; Hardware 012476; Installation Instructions 113120
007031A	128300	6	1974 Aug	7031 Console Connector Kit	many dual-channel organs	Leslie Speaker Set Models 60, 70	Control Assembly 128260; Hardware Package 128320; Installation Instructions 128300
007191A	141267	4	1979 Feb	7191 Console Connector Kit	two and three channel organs with 9-pin outplug	Leslie Speakers 700 and 710	Console Connector 141264; Cable Assembly, 9-conductor 021600; Echo Control 101480; Tremolo Control 043281; Hardware Package 141268
007270A	113960	4	1976 Apr	7270 Console Connector Kit	single-channel organs	Leslie Speakers having 9-conductor outputs	Console Connector Assembly 113910; Cable Assembly 9-conductor 30-foot 021600; Oiler 053025; Hardware Package 136140; Adapter Package 132670; Tremolo Control brown 043281ebony 043299; ivory 043307; Echo Control brown 029397; ebony 029405; ivory 029413
007271A	034447	4	1971 Dec 20	7271 Console Connector Kit	for Hammond Consoles: M-1, M-2, M.3, M-100, L-100	120, 125, 145, 147, 147RV, 225, 247, 247RV.	Console Adapter 027011; 6 conductor Cable 017277; Console Connector 012617; Instructions 034447; Tremolo Control brown 012625; ebony 012633; Ivory 012641; Echo Control brown 029397; ebony 029405; ivory 029413
007830A	137354	10	1976 Sep	7830 Console Connector Kit	various one- and two-channel organs	Leslie Speaker Models 130, 330, 820, 860	Console Connector 137283; Cable Assembly, 11-conductor, 30-foot 137357; Hardware Package 137356; Switch Assembly Echo/Tremolo, black 137342; Oiler 053025
007830B	137354	10	1978 May	7830 Console Connector Kit	various one- and two-channel organs	Leslie Speaker Models 130, 330, 820, 860	Console Connector 137283; Cable Assembly, 11-conductor, 30-foot 137357; Hardware Package 137356; Switch Assembly Echo/Tremolo, black 137342; Oiler 053025
007850A	138492	8	1977 Dec	7850 Console Connector Kit	various two-channel organs	Leslie Speaker Models 705, 705C, 720	Console Connector 138488; Cable Assembly, 11-conductor, 30-foot 137357; Hardware Package 137356; Switch Assembly Echo/Tremolo, black 137342; Oiler 053025
008000A	034074	3	1968 Oct	8000 Console Connector Kit	Hammond Consoles: A,	Leslie Models: 122, 122V,	6x4 Adapter 048082; 6x5 Adapter 048090; Console Connector 018432;

					B, C, D, E, BV, CV, B-2, C-2, RT-2, B-3, C-3, RT-3	122RV, 142, 222, 222RV	Oil Tube 053025; Instructions 034074; Tremolo Control brown 015594; ebony 015602; 05610 ivory
008000B	034074	4	1971 Mar	8000 Console Connector Kit	Hammond Organ Models A, B, C, D, E, BV, CV, B-2, B-3, C-2, C-3, RT-2, RT-3	Leslie Speaker Models: 122, 122V, 122RV, 222, 222RV	Console Connector 018432; 6x4 Adapter 048082; 6x5 Adapter 048090; Oiler 053025; Instructions 034074; Tremolo Control brown 015594; ebony 015602; 05610 ivory
008000C	034074	4	1972 Aug	8000 Console Connector Kit	Hammond Organ Models A, B, C, D, E, BV, CV, B-2, B-3, C-2, C-3, RT-2, RT-3	Leslie Speaker Models: 122, 122V, 122RV, 222, 22RV	Console Connector 018432; 6x4 Adapter 7-pin 048082; 6x5 Adapter 8-pin 048090; Oiler 053025; Instructions 034074; Tremolo Control brown 015594; ebony 015602; 05610 ivory
008000D	034074	4	1977 Jul	8000 Console Connector Kit	Hammond Organ Models A, B, C, D, E, BV, CV, B-2, B-3, C-2, C-3, RT-2, RT-3	Leslie Speaker Models: 122, 122V, 122RV, 222, 22RV	Console Connector 018432; 6x4 Adapter 7-pin 048082; 6x5 Adapter 8-pin 048090; Oiler 053025; Instructions 034074; Tremolo Control brown 015594; ebony 015602; 05610 ivory; Hardware package 011353
008000E	034074	4	1979 Sep	8000 Console Connector Kit	Hammond Organ Models A, B, C, D, E, BV, CV, B-2, B-3, C-2, C-3, RT-2, RT-3	Leslie Speaker Models: 122, 122V, 122RV, 222, 22RV	Console Connector Assembly 018432; 6x4 Adapter 7-pin (includes 6x5 Adapter 8-pin) 132910; Oiler 053025; Instructions 034074; Tremolo Control brown 015594; Hardware package 011353
008001A		6		8001 Console Connector Kit	Hammond Models B-2, B-3	Leslie Speakers: 122, 122V, 122RV, 142, 222, 222RV	Console Connector 047357; Console Connector Extension 047365; Cable Assembly 6-conductor 30-foot 017277; Installation Instructions 047472; Oiler 053025; Tremolo Control brown 015594; ebony 15602; ivory 15610
008001B	047472	2	1970 Jan 12	8001 Console Connector Kit	Hammond Models B-2, B-3	Leslie Speakers: 122, 122V, 122RV, 142, 222, 222RV	Console Connector 047357; Extension 047365; 6 Conductor Cable 017277; Instructions 047472; Oiler 053025; Tremolo Control brown 015594; ebony 15602; ivory 15610
008001C	047472	4	1972 Sep	8001 Console Connector Kit	Hammond Models B-2, B-3	Leslie Speakers: 122, 122V, 122RV, 142, 222, 222RV	Console Connector 047357; Console Connector Extension 047365; Cable Assembly 6-conductor 30-foot 017277; Installation Instructions 047472; Oiler 053025; Tremolo Control brown 015594; ebony 15602; ivory 15610
008002A	047480	4	1976 Jan	8002 Console Connector Kit	Hammond Models C-2, C-3	Leslie Speaker Models 122, 122RV, 142, 242	Console Connector 047357; Console Connector Extension 047373; Cable Assembly 6-conductor 30-foot 017277; Installation Instructions 047472; Oiler 053025; Tremolo Control brown 015594; ebony 15602; ivory 15610; Hardware Package 047423
008020A	036913	4	1969 Aug 18	8020 Console Connector Kit	Hammond E-100 Series, K-100 Series	E-100 Series: 122, 122V, 122RV, 142, 222, 222RV; K-100 Series: 122, 142, 222	Console Connector 038208; Console Adapter 042754; 7 to 5 Adapter 062091; 6 Conductor Cable 017277; Instructions 036913; Oiler 053025; Tremolo Control brown 042168; ebony 042176; ivory 042184; Echo Control brown 042200; ebony 042218; ivory 042226
008030A	059551	4	1971 Nov 3	8030 Console Connector Kit	Hammond H-100 Series	Leslie 610 Speaker	Console Connector 059577; 9 Conductor Cable 021600; Instructions 059551; Oiler 053025; Lower Rotor Control brown 059220; ebony 059238; ivory 059246; Upper Rotor Control brown 059171; ebony 059189; ivory 059197;
008066A	032789	8	1969	8066 Console	Hammond	Leslie 142,	Console Connector 032698; 6

008066B	032789	2	Aug 1971 Jan 27	Connector Kit 8066 Console Connector Kit	X-66 Hammond X-66	122, 222; #12 Hammond Speaker Leslie Speaker Models 122, 122V, 122RV, 142, 222, 222RV; HAMMOND #12 Speaker	Conductor Cable 017277; Instructions 032789; Oiler 053025; Tremolo-Echo Control brown 032706; ebony 032714; ivory 032722 Console Connector 032698; 6 Conductor Cable 017277; Instructions 032789; Oiler 053025; Tremolo-Echo Control brown 032706; ebony 032714; ivory 032722
008216A	035386	4	1972 Sep	8216 Console Connector Kit	Hammond H-100 Series	Leslie 122, 142, or 222	Console Connector Assembly 015644; Cable Assembly 017277; Tremolo Control brown 015594; ebony 015602; ivory 15610; Oiler 053025; Installation instructions 035386;
008240A	035956	4	1976 May	8240 Console Connector Kit	Hammond Organ Models H-100, H-200, H-300 Series	Leslie Speaker Models 122, 142, 242, in conjunction with Hammond #10 Speaker	Console Connector Assembly 015644; Hardware Package 039503; Cable Assembly 6-conductor 30-foot 017277; Tremolo Control brown 015594; ebony 015602; ivory 015610; Echo Control brown 024240; ebony 024232; ivory 024224; Oiler 053025
008400A	035634	5	1971 May 19	8400 Console Connector Kit	Hammond Organ models: A, B, C, D, E, RT, BV, CV	Leslie Speaker Models: 122, 122RV, 222, or 222RV in conjunction with Hammond speaker	Console Connector 018432; 7 Pin Adapter 048082; 8 Pin Adapter 048090; Oiler 053025; 6 Conductor Cable Assy. 017277; Echo Control Assy. (4H) 030825; Trem Control brown 015594; ebony 015602; ivory 15610; Echo Control brown 032243; ebony 032250; ivory 032268
008402A	047456	4	1970 Jan 19	8402 Console Connector Kit	Hammond C-2, C-3	LESLIE Speakers: 122, 122V, 122RV, 142, 222, 222RV	Console Connector 047357; Extension 047373; 6 Conductor Cable 017277; Instructions 047456; Oiler 053025; Trem Control brown 015594; ebony 015602; ivory 15610; Echo Control brown 032243; ebony 032250; ivory 032268
008800A	141119	4	1978 Nov	8800 Console Connector Kit	Hammond Organ Models D-100, RT-2, RT-3, A, B, C, D, E, BV, CV, RT, B-2, B-3, C-2, C-3	Leslie Speakers 715, 815, HL722, HL822	Console Connector 141109; Hardware Package 141118; Switch Assembly, FIXED/FAST, black 141112; (Cable Assembly 137357 included with speaker)
008805A	141588	7	1980 Jan	8805 Console Connector Kit	All single channel organs with built-in speaker systems	Leslie Speakers 315, 415, HL422, 715, 815, HL722, HL822	Console Connector Assembly 141576; Switch Assembly, Fixed/Rotary/Organ 141579; Hardware Package 137356; Oiler Package 053025; (Cable Assembly 137357 included with speaker)
009500A	044545	6	1976 Sep	9500 Console Connector Kit	Hammond Organ Models B-2, B-3	Leslie Speaker Model 760, 770, 825	Console Connector Assembly 042440; Console Connector Extension 042432; Cable Assy, 9-Cond, 30-ft 021600; Oiler 053025; Hardware Package 044552; Echo Control brown 032243; ebony 032250; ivory 032258; Trem Control brown 042606; ebony 042614; ivory 042622
009503A	044560	6	1975 Jan	9503 Console Connector Kit	Hammond Organ Models C-2, C-3	Leslie Speaker Model 760, 770, 825	Console Connector Assembly 042440; Console Connector Extension 042648; Hardware Package 044552; Cable Assy, 9-Cond, 30-ft 021600; Oiler 053025; ; Echo Control brown 032243; ebony 032250; ivory 032258; Trem Control brown 042606; ebony 042614; ivory 042622
009503B	044560	6	1978 May	9503 Console Connector Kit	Hammond Organ Models C-2, C-3	Leslie Speaker Model 760, 770, 825	Console Connector Assembly 042440; Console Connector Extension 042648; Hardware Package 044552; Cable Assy, 9-Cond, 30-ft 021600; Oiler 053025; ; Echo Control brown 032243; ebony 032250; ivory 032258; Trem Control brown 042606; ebony 042614; ivory 042622

009510A	044628	6	1975 Dec	9510 Console Connector Kit	Hammond Organ Models A- 100, D-100, RT-2, RT-3	Leslie Speaker Model 760, 770, 825	Console Connector Assembly 043604; Console Connector Extension 043612; Hardware Package 044552; Cable Assy, 9-Cond, 30-ft 021600; Oiler 053025; ; Echo Control brown 032243; ebony 032250; ivory 032258; Trem Control brown 042606; ebony 042614; ivory 042622
011593A	011601	2	1968 Mar 20	011593 Five Station Control Center	organs that are normally connected to a Leslie with one of the following adapters: 27-1, 27-1, 27-5, 27-6, 27-8, 27-9, 6091-7, 6116-7, 6202-7, 013342	120, 120C, 125, 145, 147RV, 247RV	
016444A	016550	3	1967 Oct 24	016444 Console Connector Kit	Hammond Organ Series E- 100, A-100, M-100	Leslie 125, 145, 147, 247	Console Connector Chassis 016352
021709A	022475	1	1970 Oct 27	021709 Leslie Power Relay Kit 9 pol		9 pol Leslies	
023879A	023911	2	1968 Apr 22	023879 Adapter - works with 126 Console Connector Kit	Hammond Model T - 100, T-200	Leslie 120, 125, 145, 147, 247	
034496A	034512	2	1995	034496 Power Relay		Leslie 122, 122RV, 125, 225, 142, 145, 147, 147RV, 245, 247, 247RV	Power Relay Assembly 117V 60 Hz 022202
039099A	039123	2	1996 Jun	039099 Power Relay		Leslie 125, 225, 145, 147	Power Relay Assembly 220V 50 Hz 039107
043075A		1		043075 Console Connector and Controls	Hammond M-3	Leslie 760, 770	
062091A	062174	1	1967 Dec 18	062091 Adapter 7 to 5	in conjunction with Leslie Console Connector Kits when connected to the late model Hammond organs		
138658A	138845	4	1976 Dec	138658 Adapter 9- and 11-pin	organ with 9- conductor outplugging, 9-conductor console connector kit or appropriate combo preamp	addition of a new series 11- conductor type Leslie	
138851A	138857	2	1976 Nov	138851 Adapter 117V	various 1- and 2- channel organs for use with: Single channel organs with (or without) a built-in rotor	Leslie 11- conductor (new series) speakers	
141835A	141848	4	1980 Jun	141835 Leslie 215 Control Center		Leslie Speaker Model 215	

					and some two channel organs with separate Flute/Tibia speaker		
141835B	5C/141 848	4	1980 Nov	141835 Leslie 215 Rotosonic Speaker System; Leslie 215 Control Center; Leslie 4 OHM Crossover Network			