IESTIE 8000 CONSOLE CONNECTOR KIT

For Hammond Consoles: A, B, C, D, E, BV, CV, B-2, C-2, RT-2, B-3, C-3, RT-3 To Leslie Models: 122, 122V, 122RV, 142, 222, 222RV


The Leslie 8000 Console Connector Kit connects any of the consoles listed above to a single Leslie speaker. The kit includes a console connector and a single Tremolo-Chorale switch. It also contains all the hardware necessary for this

installation. Contents of Kit: 1 - 6X4 Adapter 1 - 6X5 Adapter 048090

2 - Screw. 8 x 1/2 1 - Tremolo Control 1 - Console Connector 018432 015594 Brown 015602 Ebony 1 - Instructions 5 - Insulated Staple 028464 015610 Ivory 1 - 011 Tube 2 - Screw. 6 x 1/2 2 - Wire Nut

To install the kit-

1. Attach the Tremolo-Chorale switch case to the wooden rail in front of the lower manual with the wood screws provided. Use the two mounting holes in each case which best center the wood screws in the rail.



*Do not twist these wires before inserting them into the wire nut-

- Remove the console back, and pass the Tremolo control cable from the switch to the interior of the console in one of the following ways:
 - a. Push a small screwdriver over the felt dust seal between the lower manual and the knee pamel. Pass the cable through this opening into the console. From the back of the organ, reach behind the tone generator and pull the cable through.
 - b. Run the cable down along the corner where the knee panel and the end of the console join, then under the generator compartment to the back. Cut a small notch in the edge of the bottom shelf, and pass the control cable through it.
- Mount the console connector inside the rear generator compartment near the left-hand side of the preamplifier, using the wood screws provided.
- Connect the Tremolo control cable to the brown POT cord from the console connector with the wire nuts provided.
- Remove the wires from the "G-G" terminals on the preamplifier, and connect them to the screw terminals on the console connector.
- Attach the red and black wires from the console connector to the "G-G" terminals on the preamplifier.
- Attach the yellow wire from the console connector to any ground point on the preamplifier.
- a) Hammond A, B, C, D, E, BY, CY: Attach the brown wire from the console connector to the B+ terminal on the preamplifier. Do not disturb the wire already connected to this terminal.
 - b) Hammond 8-2, C-2, RT-2: Attach the brown wire from the console connector to the black wire on the octal B+ adapter furnished with the kit. Cover this connection with an insulating slewe, remove the 6X5 on the preamplifier from its socket, plus the adapter into this socket, and plus the 6X5 into the adapter.
 - c) Hammond 9-3, C-3, RT-3; Attach the brown wire from the console connector to the black wire on the 7-pin miniature 8+ adapter furnished with the kit. Cover this connection with an insulating sleeve, ensove the 640 on the presumplifier from its socket, plug the adapter into this socket, and plug the 6X4 into the adapter.
- 9. Replace the console back.
- Connect the speaker using the cable provided with the console. Set the tone
 cabinet volume according to the instructions in the owner's manual. The
 installation is now complete.

SERVICE INFORMATION

018432 CONSOLE CONNECTOR





08457 08093 048157 47K IW IGNED 250V 15K 1/2 W

Tremolo Control Parts List:

012260	Switch Case, Brown	
012278	Switch Case, Ebony	
012286	Switch Case, Ivory	
042911	Switch, Lever, 2 position	
048108	Switch Retainer (2 reg'd)	

048702 Switch Case Cover, Brown 048710 Switch Case Cover, Ebony 048728 Switch Case Cover, Ivory 048066 Knob, Brown 048074 Knob, Ebony 029140 Screw, TCF, 6-32 x 3/8, RH



Ordering Parts:

Standard hardware, connectors, and electronic components may be obtained locally. Non-standard items may be obtained through a Leslie speaker dealer, or from Electro Music. Orders should include part numbers, as shown above.