

LESLIE FIVE STATION CONTROL CENTER #034751
(117V,60Hz)

The Leslie Five Station Control Center, 034751 allows the dealer to demonstrate from One to five Leslie speakers at the same time with a single Hammond console. Any console set up to play with a Leslie Speaker 122, 122V, 122RV, 142, 222, or 222RV may be used as a demonstrator. Refer to the Leslie price sheet for Console Connector kits which may be used with this installation.

INSTALLATION:

1. If the console is not already equipped with a Console Connector, install the appropriate kit, but do not mount or connect the Tremolo control switch.
2. Remove the Five Station Control Center from its shipping container and attach the legs.
3. Inside the console, connect the 018432 Console Connector pigtail to the zip cord from the Control Center. Use wire nuts to make this connection.
4. Plug the Control Center cable into the 6-contact Leslie socket at the console. Use the 035659 adapter furnished if the console has a 5-contact tone cabinet socket.
5. Plug the cables from the Leslie Speakers into the sockets on the Control Center junction box.
6. Plug the Control Center power cord into any polarized 117V 60Hz receptacle which can supply 13.5 Amperes. The unit is now ready to operate.

OPERATION:

Each of the illuminated speaker switches changes from amber to green as its speaker is selected to play; the Tremolo switch is blue in the "Tremolo" position and white in the "Chorale" position. The speakers and Control Center are switched on and off automatically with the console through an internal relay circuit. The unit is protected by a 15 ampere fuse, and a parts list and schematic diagram appear on this page should any service be necessary.

PARTS LIST:

011635 Base & Column Assy	061721 Plug, 6 Pin
011676 Cable Clamp	011254 Relay, DPDT, 10 A
010322 Cap w/Clamp	018036 Resistor, 1.2K 1/2W 10%
034793 Fuse, 15 Amp	060459 Socket, 6 Contact
055178 Fuseholder	012542 Switch Assy, Tremolo, Wht-Blu
012757 Lamp, Submin, 1768	012591 Switch Assy, Echo, Amber-Green
011528 Leg Assy	011718 Transformer, 6V
035659 Adapter, Cable	

Ordering Parts:

Standard hardware, connectors, and electronic components should be ordered locally. Non-standard items may be obtained through a Leslie speaker dealer. Orders should include part numbers listed on the reverse side of this sheet.

